RAYNESYS



Raynesys Folding Camping Table
Assembly Instruction

step 1


Included Parts:

- ① Main Table
- 2 2 x Hanging Hooks

step 2

Unfolding Instructions:

- 1 Unlock both side hooks.
- 2 Unfold the tabletop and flatten the middle bar upwards.
- ③ Pull out the table legs and select the appropriate height to use (36/48/62 cm).




step 3

Storing Instructions:

- 1 Press the middle bar down into a "V" shape.
- ② Hold the table legs and one side of the tabletop to fold it towards the middle.
- 3 Lock both side hooks.

Note: Equipped with 2 metal hooks can be hung on the side of the frame hanging holes.



Warning:

Do not place heavy objects on both sides of the tabletop to avoid uneven stress on the desktop and the risk of toppling. The best use is within the area shown in the figure, and the maximum bearing capacity is **75KG/165LBS**. Do not use it overweight to avoid damage to the product.

