







Raynesys Instant Cabin Tent

User Manual



-  Quick Setup
-  Breathable
-  Sun Protection
-  Windproof
-  Waterproof
-  Mosquito-proof

Specification

Product: Instant Cabin Tent

Material: 210T Polyester + 300D Oxford Cloth

Size: 91 inch*91 inch*82 inch

Capacity: 4 Persons



Package Contents

 1x Tent	 1x Carrying Bag	 2x Accessory Organizer Bags	 1x Gear Loft
 4x Windproof Ropes	 1x Rainfly	 8x Ground Stakes	 4x Extension Poles

Assembly Steps

Step 1



Remove your tent from the carrying bag, and lay it on the ground.

Step 2



Spread out the corners of the tent, and locate the center hub on the side walls of the tent. Firmly pull the strap attached to the center hub until side walls pop out.

Step 3




Unfold the top of the tent (with one person pulling the two sides of the tent), and push upwards until the top pops out. Then secure the anchor bags at the four corners of the tent with stakes.

Step 4



Locate extension poles of four corners, align the male end of the pole with the female end, and twist tightly.

Step 5



Align the corners of the rainfly and install it. Secure the tent by attaching windproof ropes at the center hubs of the four walls.

Disassembly Steps

Step 1



Remove all ground stakes and the windproof ropes at the center hub.

Step 2



Remove the rainfly and disassemble the extension poles at four corners. Close all windows. (BUT do not zipper up the doors.)

Step 3



Pull the strap on the center hub from inside the tent until the top collapses.

Step 4



Push the center hub on the wall inward by hands until all four walls disengage.

Step 5



Fold the four corners of the tent inward. Bring all the hubs together.

Step 6



Tighten the tent with straps. Place the tent in the carrying bag with the hubs going into the bag first.

⚠ Warning: Keep all flame and heat sources away from this tent fabric.

This tent is made of flame-resistant fabric which meets CPAI-84 specifications. IT IS NOT FIRE-PROOF. The fabric will burn if left in continuous contact with any flame source. The application of any foreign substance to the product fabric may render the flame-resistant properties ineffective.

DO NOT use fuel-burning devices inside or near tent materials.

DO NOT permit children to light matches, operate burning appliances, or handle any flame sources in or near the tent.

- Do not smoke, use matches, candles, or open flames of any kind in or near the tent.
- Do not refuel lanterns, stoves, or heaters inside the tent.
- Do not cook inside the tent.
- Do not store flammable liquids inside the tent.

⚠ Warning: Keep clear of overhead power lines.

- Do not set up your tent under trees because of potential lightning strikes or falling tree limbs in inclement weather.
- For best results in windy conditions, position the narrow end of the tent into the wind.
- Secure with all stakes and guylines provided to prevent property damage or personal injury.
- Under certain conditions (cold weather, high humidity, etc.) condensation will form on the inside of your tent. Condensation is caused by water vapor from your breath, perspiration, or any wet clothing inside the tent. It is NOT LEAKAGE through the tent fabric. It can be minimized by removing wet clothing from your tent and by providing good ventilation throughout the tent.
- Never store the tent, even for a short period of time, without drying it thoroughly and brushing off caked dirt. Do not pack stakes inside your tent. Use a separate storage bag.
- Stakes should be removable by pulling on the stake itself never pull on the tent to remove the stake.
- Do not leave your tent set up for weeks at a time. Be aware that exposure to ultraviolet rays from the sun can seriously damage material and/or cause it to become discolored.

Thank You for Your Order

Dear Customer,

Words cannot express how grateful we are that you have chosen Raynesys! Our Raynesys is, and always has been, committed to providing users with high-quality and cost-effective products that make their lives smarter and easier. Your trust is greatly appreciated!

If you have any questions about Raynesys Tent, please scan the QR code below and write down your questions, or you can send the relevant questions to the email below, we have a professional service team to solve your problems at the first time!

May all the goodness and warmth come as it should! Looking forward your next visit and sincere suggests.



 E-mail: cs@iraynesys.com